

FAQ エコキュート

エコキュートの入力

エコキュートは、付属品の造作部品の中にあります。

- ① 「付属品」をクリックする
- ② 「造作部品」をクリックする
- ③ 「エコキュート」を選択し、入力する

The screenshot illustrates the software interface for adding a water heater (エコキュート) as an accessory. The process is guided by three numbered steps:

- ① **付属品** (Accessories): The '付属品' icon in the left sidebar is highlighted with a red box.
- ② **造作部分** (Custom Part): The '造作部品' (Custom Parts) icon in the top toolbar is highlighted with a red box. A callout box labeled '②造作部分' points to a specific area in the main workspace.
- ③ **エコキュートを選択** (Select Eco-Cyoto): The '部品配置' (Part Placement) window is open, showing a search for 'エコキュート'. Two items are selected and highlighted with red boxes: 'エコキュート 600×680×1860' and 'エコキュート+トホップ 858×450×720'. A callout box labeled '③エコキュートを選択 ※部品探す場合は、検索欄を使うと' (Select Eco-Cyoto ※When searching for parts, use the search bar) points to the search bar in the window.

The '部品配置' window also displays various other parts like '電気温水器', 'ガスホブ', and 'トイレ', along with configuration options for size and height.

FAQ－エコキュート は以上です